

## ***Installing instruction***

### **Pievox A77\_mute**

#### **for Revox A77 Dolby Version**

#### **Necessary tools**

Phillips driver #1 und #2  
solder iron 50 Watt.

1. Remove four screws on the back of the A77 case  
remove the remote-dummy plug and pull the A77 out of the case.  
Because the rubber strips inside the case will be sticky from age maybe some force is necessary.
2. identify the line out socket with the green and violet wire
  - here the same color wire from the A77\_Mute will be soldered additional
  - the blue wire goes to the solder lug see picture
  - solder the yellow wire according to the additional instruction leaflet
  - lastly the red wire will be soldered on the solder lug on the white wire on the brake solenoid.
3. Using the screws delivered with the A77 Mute pcb  
according to picture attach the A77 Mute pcb on the „Micro input“ socket  
fasten screws
4. Push the A77 [careful](#) in its case  
insert the four screws on the back and fasten without force !  
insert the dummy remote plug

Done